



Drapeline or Truss Hanger

Setup Instructions

Step 1:

Hook a U Bolt over The pipe or Truss then lock it down with a ball end on the Upstage Side of the pipe (Images 1 & 2)



Image 1



Image 2

Step 2:

Slide 2 Ends of Trim Chain Over the U Bolt creating a loop. Lock Down with The Ball End on the DS Side of the Pipe (Images 3 & 4)



Image 3



Image 4

Step 3:

Repeat the U Bolt Process at two foot max spacing. It doesn't need to be exact, Avoid obstacles wherever possible (Image 5)



Step 4:

Slide Sections of PVC Pipe through the chain loops, and Sleeve them to each other to create an under hanging Batten from the Original Pipe (Image 6)



Step 5:

Using the Spring Loaded Pins; Lock in each PVC Pipe to the Next one in the system (Image 7)

Step 6:

Sling a Velcro hanging strap over the PVC Pipe at each white mark, Fuzzy Side Facing Down Stage. Clip the carabineer to the Double Sided Velcro Loop on the Strap. If you need to adjust the overall height, you can reposition this Velcro loop (Image 8)

*If there is anything Wrong with The Pre-Strung Scenic Element Provided, You can use the Velcro Straps and move the element to the location desired, Keeping in mind the standardized spacing in each system

An Example would be to move Hexagons to the bottom of a column to create a larger gap between Batten trim height and the Scenic Element Beginning



Image 8

Step 7:

At this stage in your set up you will add the Specific Scenic Element provided (Hex, Planks, White Boards) Please use the Provided Instruction Book For that Scenic

***Follow the installation steps backwards in order to strike safely and avoid any damage to any of the supplied hardware**

***If there are any issues or Questions with your Install please call our Office Line 303-744-6465**