You Want What? Productions, INC 2879 S Tejon St.
Englewood, CO 80110 303.744.6465
nick@ywwproductions.com



## Magnificent Module Column Setup Instructions



Front View (4' tall, semi circle)



Back View (note the jack connection plates)



Top View (with 3 threaded holes; bottom holes have no threading)



- 1- Lay out as many columns as you will need to get to the correct height. It is easiest if you can lay them out so the bottom is near its final standing location.
- 2- As you are laying out the columns, make sure the threaded inserts are on the top of each column, and the non-threaded holes are on the bottom of each column.



- 3- Take a bolt (1/4"-20 x 1 1/2" black) and washer, and insert it through the *non-threaded* into the *threaded* hole in the center front of the first two columns. Get the bolt threads started without tightening.
- 4- Move to two the side bolt holes. Again, insert the bolt from the *non-threaded* into the *threaded* hole. Adjust the relative positioning of the columns as needed to line up the holes.



5- Once all three bolts are started, tighten all three with a ratchet / wrench.



6- Repeat steps 3-5 until the entire length of the column is attached.



7- Roll the column onto its face, being careful not to stress the joints



- 8- Any column taller than 8' requires a jack brace for stability. These must be installed before standing the column to support the joints as it's walked up.
- 9- Select a jack the same height as the column. If necessary. Jacks come in three or four parts: bottom, diagonal brace, upright, and sometimes an upright extension.
- 10- Assemble the jack upright to the correct height. DO NOT YET install the bottom and diagonal brace.



- 11- Feed a velcro cinch under each connection plate on one side or the other (wherever you want the jack to be), fuzzy side down.
- 12- Set the jack upright on one or the other back edge of the columns, centered on the connection plates, with the bottom flush to the bottom of the columns. FOR COLUMNS 16' AND TALLER use two jack uprights one on each side.



13- Wrap the velcro cinch around the jack, then feed back under the connection plate. Now put the end of the cinch through the loop and cinch tightly. Repeat for each column section.





- 14- Roll the column back over onto it's back.
- 15- With one person footing, and several people lifting, walk the column up to stand.
- 16- Keep supporting the column while bolting the jack bottom and diagonal brace into place.
- 17- Immediately place 2@ 25 lbs sand bags on the jack, at the point of the triangle.
- 18- If using columns in conjunction with Magnificent Module panels, use velcro cinches or tie line to connect the panel frames to the column jack uprights.
- 19- Rinse and repeat.

